

PANELX COUNTER-TOP INSTALLATION

STEP 1: INSTALL ALL THE REQUIRED PANELX TILE INSERTS. SEE SEPARATE ASSEMBLY INSTRUCTION DOCUMENT ON HOW TO INSTALL THE PANELX TILE INSERTS ONTO YOUR STATION.

STEP 2: TAKE THE 4" X 1.75" BRACKETS PROVIDED AND PLACE THEM ON TOP OF THE PANELX POSTS WHERE YOUR COUNTER-TOP IS TO BE LOCATED. EACH COUNTER-TOP SHOULD BE INSTALLED ONTO TWO POSTS WITH THE 4" X 1.75" BRACKETS, WITH ONE POST LOCATED AT EACH END OF THE COUNTER-TOP.

SECURE THE BRACKET IN PLACE WITH ONE 3/8-16 X 2" BOLT.

NOTE, IF THERE IS A PLASTIC CAP INSIDE YOUR PANELX POST, MAKE SURE TO REMOVE IT BEFORE INSTALLING THE BRACKET.

STEP 3: PLACE THE LAMINATE COUNTER SURFACE ON TOP OF THE POSTS WITH THE INSTALLED BRACKETS. YOU WILL SEE THE PRE-DRILLED HOLES UNDER THE COUNTER-TOP THAT WILL INDICATE THE CORRECT COUNTER-TOP PLACEMENT. THEN SECURE THE COUNTER-TOP INTO PLACE USING QTY 4 X 10-12 X 1" WOOD SCREWS.

NOTE: IF INSTALLING AN L-SHAPE OR U-SHAPE COUNTER-TOP CONFIGURATION, PLEASE USE THE 3" X 3" FLAT BRACKETS AND 5/8" WOOD SCREWS PROVIDED TO SECURE THE TWO COUNTER-TOPS TOGETHER AT THE JOINT OF THE L-SHAPE.

