


COMPONENT BREAKDOWN:



HARDWARE INCLUDED:



**1" WOOD
SCREW**



**5/8" WOOD
SCREW
FOR STIFFENER
BAR USE ONLY**



**5/16-18 x 1"
SOCKET CAP
SCREW**



**5/16"
WASHER**


DISCLAIMERS

- Use all hardware provided to secure components as specified.
- This installation will require 2 or more people.
- Read all instructions and review all illustrations before installing. Failure to observe these warnings could result in injury.
- Product that is damaged by the end user due to misuse, accident, abuse, negligence or shipping is not covered under warranty.

STEP ONE

Attach the Leg Column to the Foot Plate using the 5/16-18 x 1" Socket Cap Screws and the 5/16" Washers provided.

Follow the assembly process shown below.



HARDWARE REQUIRED




STEP TWO

Place the tabletop on a soft, clean, scratch-resistant surface with the pilot holes facing upward.

Position the legs (assembled in Step 1) onto the tabletop, aligning them with the pilot holes.

Using the provided 1" wood screws, secure each leg to the tabletop. Install all 10 screws through each leg plate, ensuring the legs are firmly fastened to the surface.



**HARDWARE REQUIRED:**

1" WOOD SCREW

STEP THREE

Note: Step Three is only required for models which require a stiffener bar.

Using the provided 5/8" wood screws, position the stiffener bar onto the tabletop, aligning each end with the corresponding pilot holes. Secure it in place by inserting a 5/8" wood screw into each hole located on the stiffener bar.



HARDWARE REQUIRED:



**5/8" WOOD
SCREW**

STEP FIVE

Ensure the floor glides are properly inserted into the bottom of the foot plates, then with two or more people, carefully flip the table into an upright position.

